







## RVS Master™ Motor Flush

### Application Instructions

- RVS Master™ Motor Flush performs a deep cleansing of your engine's internal parts, and maintains the surfaces of cylinder walls, crankshaft bearings, camshafts and valves. Use before treatment with RVS Master™ Petrol/Diesel Engine Treatment for optimum results, or between oil changes preventatively.
  - Prior to starting the treatment procedure, make sure that there are no oil leaks in the engine and that the condition and quantity of the oil corresponds to the manufacturer's recommendations.
- Note:** Do not skip any of the steps in the following procedure. Doing so can significantly diminish your results.

#### Treatment Procedure

-  1 Shake Bottle well until there is no more residue on bottom of bottle. 20-30 sec.
-  2 Remove oil cap on top of engine and pour entire bottle into engine.
-  3 Start your vehicle right away and either let it idle for 1 hour OR drive it for at least 50km/35 miles. After this step is complete, you can turn the vehicle off or resume driving it normally.
-  4 After driving the vehicle for 400km/250 miles, change your oil and filter.  
**WARNING: DO NOT** delay this oil change, it could result in damage to your engine.

#### Storage and safety instructions

Store at temperatures below +40 °C (105 °F). In case of skin contact, wash with lukewarm water and soap. If the product gets in your eyes, it may cause irritation – flush with water and consult a doctor if the irritation continues. If the product is swallowed, flush the mouth with water and consult a doctor. Do not induce vomiting! Keep product out of reach of children.